



INSPECTIONS REQUIRED:

1. FOUNDATION: EXCAVATION, TRENCH CLEAN WITH STEEL IN PLACE.
2. EACH MID BOND BEAM PRE-GROUT.
3. TOP OUT PRE-GROUT.
4. FINAL: AFTER GROUT, PRIOR TO CAPPING OF WALL.

**CITY OF CORONA
BUILDING DIVISION**

COMBO BLOCK WALL DETAIL

400 S. VICENTIA AVE.
CORONA, CA 92882

PHONE: 951-736-2250 FAX: 951-279-3561

