


WEED ABATEMENT REQUIREMENT

1. WEED ABATEMENT TO BE COMPLETED AFTER INSTALLATION OF COMPLETE IRRIGATION SYSTEM AND SOIL PREPARATION BUT PRIOR TO ANY PLANTING.
 - A. FERTILIZE WITH 1 LB. ACTUAL NITRATE NITROGEN PER 1,000 SQUARE FEET AND WATER FOR 14 DAYS.
 - B. SPRAY NON-SELECTIVE SYSTEMIC HERBICIDE ON ALL EMERGED WEEDS PER LICENSED PEST CONTROL ADVISOR RECOMMENDATION.
 - C. WAIT SEVEN DAYS.
 - D. REMOVE ALL WEEDS.
 - E. FERTILIZE WITH 1 LB. ACTUAL NITRATE NITROGEN PER 1,000 SQUARE FEET AND WATER FOR 14 DAYS.
 - F. SPRAY NON-SELECTIVE SYSTEMIC HERBICIDE.
 - G. WAIT SEVEN DAYS.
 - H. GRUB WEEDS AND PERFORM PLANTING WITHIN 14 DAYS.
 - I. TOTAL WEED ABATEMENT PROGRAM BETWEEN 42 AND 56 DAYS.

(TO BE PLACED ON
ALL PARK PLANS)



APPROVED BY:

 11/23/09
 CITY ENGINEER DATE
 KIP D. FIELD

CITY OF CORONA

WEED ABATEMENT REQUIREMENT

REVISION	DESCRIPTION	BY	DATE
----------	-------------	----	------

STANDARD PLAN NUMBER: **828** SHT 1 OF 1