



NOTES

1. BATTERY BACK UP CABINET SHALL BE MOUNTED ON THE LEFT SIDE OF THE "P" CABINET LOOKING AT THE FRONT DOOR.

REVISIONS:			APPROVED BY:	CITY OF CORONA
NO.	DATE	APPRV'D		
1	10/1/20	<i>tk</i>	<i>Tom Koper</i>	10/8/2020
			CITY ENGINEER	DATE
			TOM G. KOPER	
			RCE NO. <u>C50258</u>	
				TRAFFIC SIGNAL TYPE "P" CABINET & FOUNDATION DETAILS
				STANDARD PLAN NUMBER: 532
				SHT 1 OF 1